

Brake Fluid Tester – 4598

CATCH BAD BREAK FLUID

before it destroys calipers and other brake system components

- Tester determines quality of brake fluid.
 - One battery included: 1.5V AAA.
1. Remove cap from brake fluid reservoir.
 2. Remove probe cap from brake fluid tester.
 3. Press power button on top of tester. Green LED lights up.
 4. Dip entire length of metal probes into brake fluid.
 5. After one second, match colour of LEDs with colour chart to determine brake fluid quality. Tester automatically powers off after twelve seconds of inactivity.

Note: Calibrated for DOT 4 fluid only.

